

x-ray views Start here P&R = Press & Release

P&R boxed chord 1st - then P&R Caps if shown

	For a chorded character		P&R Caps		P&R chord	
	P&R with symbol		=		+	

Every command, prefix, & character (except one finger alphas and numerals) is available whatever the state.

x-ray views are thumb side views of keys & chords.

Right hand

Left hand

--	--	--	--

• period **Space** **Return** **Tab**

NonBreak

• comma **Space** **Enter** **esc**

P&R **Alpha** to return to

--	--	--

lower case

--	--	--	--	--

P&R **Nlock** to exit

P&R **CapsLock** to exit

Nlock default layout is **N pad p** (phone)

Help/Insert **Navigation** includes Deletes

--	--	--	--	--

P&R **Navigation** to exit

Accent

--	--	--

P&R **Accent** +mark + letter or Space

--	--	--	--

Use 3post for symbols with Caps in Nlock or anywhere.

Extended character sets

--	--	--	--	--

blue symbols vary by font

--	--	--	--	--

white symbols unique to each OS

Macintosh additional character set

--	--	--	--	--

Windows additional character set

--	--	--	--	--

Windows only **Print** **Scroll** keyboard

--	--	--	--	--

ShortCut & Keep

Store 99 ShortCuts & 99 Keeps: for 1 digit: Enter # entry Enter; for 2 digit: Enter Enter # # entry Enter. To retrieve: Access # or AA##. To clear: Enter # Enter or EE## E.

--	--	--

Code+password+KeepAccess unlocks Keeps if password protected.

Create 1 to 10 ShortCut sets, each with ten 1-finger chords.

To make it easy to access sets of ShortCuts for an application, organize them into ranges like 10,11,...19 or 50,51,...59 entering up to ten ShortCuts in a range. Accessed by **10-ones** chord + **first digit**, each set gives repeated one finger access to ShortCuts in the range.

To **Access** a set of one finger ShortCuts:

P&R **10-ones**, then P&R **first digit** of two digit location.

10-ones **first digit** repeated **1-finger** chords

--	--	--	--	--

1-finger chord does ShortCut stored in 2nd digit location

More actions until exit with **Alpha**.

Commands *Primary: qwerty keyboard left side*

--	--	--	--	--

R hand L hand or **Alt** P & RELEASE to activate commands

--	--	--	--	--

Pressing any key completes and/or ends a command action

GridPad Numerical keypad on full size qwertyboards

Windows:

Macintosh:

In Mac use **Navigation** to move cursor.

--	--	--	--	--

--	--	--	--	--

--	--	--	--

Alpha exits

Gnum • period

Windows only

Numlock switches between &

--	--	--	--	--

--	--	--	--	--

Configs change settings; Config chord + 1st letter chord

--	--	--	--	--

OS=Config+o+m or w

Resets in blue

1st~Last

--	--	--

Code (empty) Create password with Q set. Unlock Keeps with Code.

Code+password + KeepAccess

Q Set+password+KAccess

If Alph On, EkaPad returns to AlphaState after 5 minutes of no chords

Off is default

Sleep **Npad** (Config+n+letter)

Mac dialog box

--	--	--	--

Wake Npd+p 0 Npd+t 0 Npd+r 0 Npd+l 0

Mac: UnPlug EkaPad to wake

Trigger Repeat & Hold-Down

--	--

To **hold down** Shift, ⌘, Option, ctrl, Alt, **press** for Trigger delay time (0.5 sec-2 secs) and then **release**. To **Repeat**, **hold down** chord and **release**. P&R any key to exit. **9 = off**

Config+†† 1 to 8 sets delay time.

Version#

--

ver together

Displays the current version of EkaPad software.

Functions

--	--	--

P&R **F** once for one digit function then P&R the number key(s)

P&R **F** twice for two digit function

Function numbers 1 through 24 work.

Restart = FF99

--	--	--	--

Restart stops & restarts computer

Names of State chords are colored: Alpha Navig Nlock CapsLock ShortCut&KeepEnter GridPad 10-ones

EkaTetra CheatSheet for the USB EkaPad
 Find additional Tools at www.ekatetra.com/support